NEW TaskCom Green Box Quick Start Quide







Microphone mode switch for talk switch on front: Up-mic is on or hot, down-mic is momentary or push-to-talk.

Headset speaker volume adjustment: UP-Alternative action talk switch mode. Push talk switch to latch or hot mic, push talk switch second time to turn of talk function or mic mute. Down-Mometary mode switch mode is non-latching or push-to-talk.

Headset microphone sensitivity gain adjustment:

Clockwise-less sensitive or more noise canceling, picks up less background noise, requires louder voice. Counter-clockwise-more sensitive, mic is hotter, picks up more background noise.

MAKING FLAT RJ11 PHONE CORD CABLES

To make **flat phone cord cables** with RJ11 modular crimp connectors, wiring is "**straight thru**", not "flipped" or mirror image, as in normal telephone to wall cables. Note in photo below--connector is facing away with clip down: *Black, Red, Green* and *Yellow*.

Wiring on both sides of cable: Yellow: CH1, Green: CH2, Red: CH3, Black: common ground. If using female to female modular coupler, make sure it is wired as straight thru, not flipped.

When making up TA4F or miniXLR4F round metal locking connector to RJ11 modular crimp connector cable, wiring on RJ11 side is same. On metal connector: Bottom-Black/ground, Middle-Yellow/CH1, Left (back inside connector view)-Red/CH3, Right (back inside connector view)-Green/CH2.









